

Temptation Cream with Iso Jojoba™ 35

This lightweight cream instantly absorbs to hydrate, mattify and soften skin.

| Phase | % | Ingredient | INCI | Supplier | Function |
|-------|-------|---------------------------------|--|----------|---------------------|
| 1 | 84.30 | Deionized Water | Water | | Aqueous Vehicle |
| 1 | 0.05 | Disodium EDTA | Disodium EDTA | | Chelating Agent |
| 2 | 0.30 | Carbopol® Ultrez 21 | Acrylates/C10-30 Alkyl Acrylate Crosspolymer | Lubrizol | Rheology Modifier |
| 3 | 0.10 | Sensiva® SC 50 | Ethylhexylglycerin | | Preservative |
| 4 | 1.20 | Lipomulse™ 165 | Glyceryl Stearate (and) PEG-100 Stearate | Vantage™ | Emulsifier |
| 4 | 1.00 | Lipocol™ C-Natural | Cetyl Alcohol | Vantage™ | Emulsion Stabilizer |
| 4 | 0.75 | Lipowax™ P Pastilles | Cetearyl Alcohol (and) Polysorbate 60 | Vantage™ | Emulsion Stabilizer |
| 4 | 0.90 | Phenoxyethanol | Phenoxyethanol | | Preservative |
| 4 | 11.00 | Iso Jojoba™ 35 | Simmondsia Chinensis (Jojoba) Butter | Vantage™ | Natural Emollient |
| 5 | 0.40 | Sodium Hydroxide (20% Solution) | Sodium Hydroxide | | Neutralizing Agent |

Procedure:

1. Add Phase 1 to main vessel. Begin mixing with a saw tooth propeller mixer. Mix until uniform.
2. Begin to heat to 80°C. Sprinkle in Phase 2 ingredient slowly. Mix until uniform.
3. Add Phase 3 ingredient. Mix until uniform.
4. Premix Phase 4 ingredients in a side beaker. Heat to 80°C.
5. Add Phase 4 premix to main vessel. Mix until uniform.
6. Begin to cool the batch. At 75°C, add Phase 5 ingredient. Mix until uniform.
7. Cool batch to 30°C.

pH: 6.30

Viscosity (TD, 4rpm, 1.5min): 168,500 cps

Stability: Ongoing

Vantage Personal Care™ - www.vantagegrp.com

All data, including any formulations and procedures, supplied to customers, to the knowledge of Vantage™, are supplied in good faith and believed to be reliable and accurate. Please note, however, that Vantage™ does not warrant or guarantee the accuracy, reliability or completeness of the information contained herein, and Vantage specifically disclaims all warranties, including warranties of non-infringement, merchantability and fitness for purpose. It is the user's responsibility to determine the suitability and completeness of such information for the user's particular application (including performing any necessary confirmatory tests). Vantage™ is not responsible or liable for any loss or damage that may occur from the use of this information. Nothing contained herein shall be construed as providing any permission, recommendation, or inducement to practice any patented invention without permission of the patent owner.