

## Chia Seed Detox Pudding

This hydrating cream with Lipobead™ Detox with Coconut Charcoal MB is hydrating, purifying, and detoxifying.

Phase	%	Ingredient	INCI	Supplier	Function
1	71.30	Distilled Water	Aqua	N/A	Aqueous Vehicle
1	1.00	Bio-Signal™ Lipid 10 MB	Glycerin (and) Phospholipid	Vantage™	Active
2	3.00	Vycerin™ GL93 Kosher USP Vegetable Glycerin	Glycerin	Vantage™	Humectant
2	0.20	KELCOGEL® CG-HA	Gellan Gum	CP Kelco	Rheology Modifier
3	5.00	Distinctive™ Emul-lipid LB	Hydrogenated Lecithin, Behenyl alcohol, and palmitic acid	Vantage™	Natural Emulsifier
4	0.10	Sensiva® SC 50	Ethylhexylglycerin	Schulke	Preservative
5	5.00	Argan Oil	Argania Spinosa Oil	Vantage™	Natural Emollient
5	5.00	Iso Jojoba™ 35	Simmondsia Chinensis (Jojoba) Butter	Vantage™	Natural Emollient
5	1.00	Chia Seed Oil	Salvia hispanica seed oil	Vantage™	Natural Emollient
5	1.00	Black Cumin Seed Oil	Nigella Sativa Seed Oil	Vantage™	Natural Emollient
5	2.50	Lipocol™ SC Pastilles	Cetearyl Alcohol	Vantage™	Stabilizer
5	2.00	Liponate™ Jojoba 20	Jojoba Esters	Vantage™	Emollient
5	0.90	Phenoxyethanol	Phenoxyethanol	Schulke	Preservative
6	2.00	Lipobead™ Detox with Coconut Charcoal MB	Mannitol (and) Cellulose (and) Charcoal Powder (and) Hydroxypropyl Methylcellulose (and) Caprylic/Capric Triglyceride	Vantage™	Visual/ Detoxifying

### Procedure:

1. Add Phase 1 to main vessel and begin propeller mixing. Mix until uniform. Heat to 80°C.
2. Premix Phase 2 ingredients and add to main vessel. Mix until uniform.
3. Add Phase 3 ingredients and hydrate at 80°C for 25 minutes.
4. Add Phase 4.
5. Premix Phase 5 ingredients in a side vessel. Place water phase on silverson and homogenize- sq hole at 6000RPM and add Phase 5 under homogenization.
6. At 35°C add Phase 6 ingredient with very slow sweep mixing.
7. Cool batch to 30°C.

Stability: 6 weeks (F/T, 45°C, 25°C)

Vantage Personal Care™ - [www.vantagegrp.com](http://www.vantagegrp.com)

All data, including the formulations and procedures discussed herein, to the knowledge of Vantage™, are believed to be correct, reliable and accurate. Please note however, that Vantage™ does not warrant or guarantee any accuracy, reliability or completeness of the information contained herein. It is the user's responsibility to determine the suitability and completeness of such information for the user's particular use (including performing any necessary confirmatory tests). Vantage™ is not responsible or liable for any loss or damage that may occur from the use of this information, nor do we warrant against any patent infringement. Nothing contained herein shall be construed as providing any permission, recommendation, or inducement to practice any patented invention without permission of the patent owner.