

Radiant Skin Concealer Stick

A velvety concealer stick with high coverage that provides smooth color laydown. The addition of Bio-Signal™ Lipid 10 MB in this emollient stick will help to provide moisturization and radiance to the skin without any irritation.

Phase	%	Ingredient	INCI	Supplier	Function
1	36.67	Liponate™ CCC MB	Coco-Caprylate/Caprate	Vantage™	Emollient
1	1.00	Textron™ Origin Rosehip Oil	Rosa Canina (Rosehip) Fruit Oil	Vantage™	Emollient
1	1.00	Bio-Signal™ Lipid 10 MB	Glycerin (and) Phospholipid	Vantage™	Active
1	10.25	RON Ti-12	Titanium Dioxide	Vantage™	Colorant
1	1.65	Unipure Yellow LC 182	CI 77492	Vantage™	Colorant
1	0.03	Unipure Red LC 381	CI77491	Vantage™	Colorant
1	0.13	Unipure Black LC 989	CI 77499	Vantage™	Colorant
1	10.00	MLB	Polyglyceryl-4 Isostearate & Coco-Caprylate/Caprate & Distearidimonium Hectorite & Polyglyceryl-3 Polyricinoleate & Sorbitan Isostearate	Vantage™ / Sunjin	Rheology Modifier
2	9.00	Jjoba Wax Flakes	Hydrogenated Jojoba Oil	Vantage™	Structuring Agent
2	9.00	Lipovol™ GTB	Tribehenin	Vantage™	Structuring Agent
2	1.00	Euxyl® PE 9010	Phenoxyethanol (and) Ethylhexylglycerin	Schulke	Preservative
3	10.00	Gransil PSQ	Polymethylsilsesquioxane	Grant Industries	Aesthetic Powder
3	6.00	Sericite PHN	Mica	Presperse	Filler
3	4.00	SUNSIL OLEO-130	Silica (and) Cetyl alcohol	Vantage™ / Sunjin	Aesthetic Powder

Procedure:

1. Add Phase 1 into vessel and mix well with prop mixing.
2. Switch to homogenization and mill pigments until uniform. Switch back to prop mixing.
3. Add Phase 2 to main vessel and continue to mix well. Heat to 75-80°C.
4. Add Phase 3 to main vessel until smooth. Pour samples in stick compounds at 70-72°C.

Stability: 6 weeks @ (RT, F/T & 45°C) is acceptable