

Second Skin Foundation

A silky foundation that is breathable and applies evenly with smooth color coverage.

Phase	%	Ingredient	INCI	Supplier	Function
1	25.74	Liponate™ CCC MB	Coco-Caprylate/Caprata	Vantage™	Emollient
1	1.00	Textron Origin Rosehip Oil	Rosa Canina (Rosehip) Fruit Oil	Vantage™	Emollient
1	2.50	Cola™ Mulse 3GO	Polyglyceryl-3 Oleate	Colonial Chemical	Emulsifier
1	2.50	Distinctive™ Emul-Lipid BA	Polyglyceryl-10 Mono/Dioleate (and) Polyglyceryl-3 Oleate (and) Glycerin (and) Phosphatidylglycerol	Vantage™	Natural Emulsifier
1	1.00	Bio-Signal™ Lipid 10 MB	Glycerin (and) Phospholipids	Vantage™	Active
1	15.00	Distinctive™ Gel ID	Isododecane (and) Quaternium-90 Bentonite (and) Propylene Carbonate	Vantage™	Rheology Modifier/ Stabilizer
2	10.25	Unipure White LC 987 AS	CI 77891 (and) Triethoxycaprylylsilane	Sensient	Colorant
2	1.60	Unipure Yellow LC 182 AS	CI 77492 (and) Triethoxycaprylylsilane	Sensient	Colorant
2	0.30	Unipure Red LC 381 AS	CI 77491 (and) CI 77499 (and) Triethoxycaprylylsilane	Sensient	Colorant
2	0.13	Unipure Black LC 989 AS	CI 77499 (and) Triethoxycaprylylsilane	Sensient	Colorant
3	1.00	Euxyl® PE 9010	Phenoxyethanol (and) Ethylhexylglycerin	Schulke	Preservative
4	8.00	Orgasol® Green Touch	Nylon-11	Vantage™/Arkema	Functional Powder
5	30.18	DI Water	Aqua		Aqueous Vehicle
5	0.80	Sodium Chloride	Sodium Chloride		Stabilizer

Procedure:

1. Add Phase 1 to main vessel and begin propeller mixing. Mix until uniform.
2. Add Phase 2 to main vessel and switch over to Silverson for high speed mixing. Mix until uniform.
3. Switch back to propeller mixing. Add Phase 3 ingredient. Mix until uniform.
4. Add Phase 4 ingredient. Mix until uniform.
5. Premix Phase 5 ingredients until soluble.
6. Switch back to Silverson for high speed mixing. Add Phase 5. Mix until smooth and uniform.

Viscosity (spindle, speed): 4@ 20 4,500 cps

Stability: Stable 25°C, F/T; 45°C slight leakage

Vantage Personal Care™ - www.vantagegrp.com

All data, including the formulations and procedures discussed herein, to the knowledge of Vantage™, are believed to be correct, reliable and accurate. Please note however, that Vantage™ does not warrant or guarantee any accuracy, reliability or completeness of the information contained herein. It is the user's responsibility to determine the suitability and completeness of such information for the user's particular use (including performing any necessary confirmatory tests). Vantage™ is not responsible or liable for any loss or damage that may occur from the use of this information, nor do we warrant against any patent infringement. Nothing contained herein shall be construed as providing any permission, recommendation, or inducement to practice any patented invention without permission of the patent owner.